

608B E-Pipe Instructions & Tips

When you receive your 608B e-pipe first charge the battery by removing the stem. Turn the stem counterclockwise to remove. Then remove the F1 tankomizer by turning it counterclockwise. Screw the USB charger into the same port the tankomizer was removed from. plug the A/C to USB adapter in to a outlet and plug the USB charger into the adapter. Charge time about 2 hours.

To fill the tankomizer remove the plug and locate the fill hole.

Then insert the needle bottle into the fill hole and fill to the top of the window. Reinstall the plug making sure to line up the dowel. After the pipe



battery is charged remove the charger and install the tankomizer in the battery/bowl by screwing in clockwise. Replace the pipe stem by turning it clockwise, CAUTION do not over tighten the stem.



The 608B e-pipe can also be used with a 510 cartomizer in place of the F1 tankomizer. The 608B Has an automatic switch that can be damaged if e-liquid gets in the switch, please do not over fill the tank or cartomizer to prevent leakage.