

EGO T CE4 Kit Instructions

The EGO T battery has a five click on-off feature, to turn the battery on push the button five times and the led will blink three times. Pushing the button five times again will turn it off. Newer batteries may have a three click on-off. The battery needs to be charged when you receive the kit. To charge screw the USB charger lightly on the battery and plug it into any powered USB port, charge time is about 2 hours. While the battery is charging fill the CE4 clearomizer with e-liquid and Prime by taking 2-3 puffs without pushing the button After charging screw the CE4 clearomizer on the battery push the button while inhaling and enjoy. Do not over tighten the clearomizer to battery!!!

CE4/CE4+/iClear 16 Clearomizer Filling Instructions

To fill the CE4 remove the mouthpiece by turning counterclockwise and pulling it off the body. Then insert the needle bottle or drip tip between the body and silicone stop. Do not force the needle or drip tip past the silicone seal. Fill to the bottom of the silicone stop with your e-liquid. Remove the needle bottle or drip tip and replace the mouthpiece by pushing in and tighten clockwise.

Wait several minutes for the wick to get liquid to the heating coil before use, you may also take three puffs without pushing the button to prime. During use tip the CE4 back to keep the wick wet occasionally. The needle bottle cap may be used on a e-liquid bottle by removing the drip tip of the e-liquid bottle.

